

TECHNICAL DATA: Intersorb 8 to 12 mesh Indicating and Non-indicating soda lime. Grade D

Product names:

Intersorb 812 NI (non-indicating)
Intersorb 812 WV (indicating)

Intersorb 812 is comprised of 2 mm cylindrical granules and has been produced to achieve the maximum carbon dioxide absorption and optimum physical properties. This is to achieve the most suitable performance within diving rebreathers.

Intersorb 812 has been tested to NATO test standard STANAG No 1411.

Chemical composition: Intersurgical tests.

	Intersorb 812 NI	Intersorb 812 WV
Calcium Hydroxide	97 %	97 %
Sodium Hydroxide	3 %	3 %
Ethyl Violet	NIL	0.03 %

Note, these figures represent the dry constituents. The product will additionally contains 14 % to 18 % water.

Physical properties: NATO test standard STANAG No 1411

i flysical properties. With a tec		
	Intersorb 812 NI and WV Typical data	Specification
Particle size		
Over 2.80 mm	0.6 %	1 % max
2.00 to 2.80 mm	25%	30 % max
1.40 to 2.00 mm	Balance	Balance
0.600 to 1.40 mm	6 %	20 % max
Under 0.600 mm	0.5 %	1 % max
Moisture content	16 %	14 % to 20 %
Hardness	87 %	80 % minimum
(% Retained on 1.4mm screen)		
Resistance to flow	1.4 mbar unused	
(40 L/min, absorber 10 cm	1.6 mbar used	
diameter, 12.5 cm height, volume 1 litre.)		

Intersurgical Limited

Registered in England Reg. No. 1488409

Directors S K WIlliams H Bellm K Jacob D Williams P Jassell







Carbon Dioxide absorption: NATO test standard STANAG No 1411

	Intersorb 812 NI and WV Typical data	Specification
Time to 0.5 % CO ₂ breakthrough (minutes)	100 minutes	80 minimum
CO ₂ capacity L/kg	150 L/kg	120 L/kg minimum

105 ml absorbent in 30 mm diameter tube. Challenge gas: 3.0 L/min air containing 5 % CO₂. Humidity 100 % Temperature 20°C

4th April 2011 Mike Holder Product and Development Manager for Absorbents. Intersurgical Ltd. Tel direct 0044 (0)1189 656361 Fax 0044 (0)1189 656356



